

SET UP

1. Access the power cable by lifting the display cover via the cable notch and carefully remove the power cable from its storage area.



2. Check to make sure the power cable runs through the cable notch before laying the display cover back in place.



Light Output (Maximum Set Point)

1. To set the maximum light output, toggle the slide dimmer up/down 5 times (up/down, up/down, up/down, up/down, up/down).
2. Then set the slide dimmer to the position you want as your maximum light output (Maximum Set Point).
3. **DO NOT TOUCH THE SLIDE DIMMER FOR 15 SECONDS**
This pause will lock in the max light output (max. set point) You may see the LEDs flash, which is expected and signals the end of the 15 second set point window.
4. The maximum light output has now been established. To change the maximum light output, repeat steps 1-3.

Scan this QR code to watch a video on how to use the demo kit and set a maximum set point.

bioslighting.com/demokit

